







HOW TO USE A 24 HOUR TIMER SWITCH



-  1 Locate the dial clockwise until the arrow points to the current time
-  2 Push down the segments for the times you want the device to be ON
-  3 Insert the timer into the wall socket and plug in your appliance into the timer
-  4 Ensure the switch on the side of the timer is set to the clock icon, as this is the timer

